

Montageanleitung Carbon Rahmenschutz BMW S1000 RR Fitting Instruction Carbon Frame Cover BMW S1000 RR

Stand 01/10

Anbau:

1. Der Rahmen muss trocken und fettfrei sein.
2. Den Kleber möglichst dünn an vielen Stellen am Rahmen auftragen (siehe Foto)
3. Die Schoner anschließend möglichst fest am Rahmen andrücken und mit Kabelbindern fixieren um eine spaltfreie, feste Passung zu gewährleisten.
4. Den Kleber über Nacht antrocknen lassen.

Mounting:

1. The frame should be dry and greaseless.
2. Put the glue fine on the frame to many positions (as shown on the picture).
3. Push the covers hard on the frame and fix it with cable clips to receive a gap free, exact fitting.
4. Let the glue dry over night.



Technical Data Terostat 9220:

- Colour: black
- Density: approx. 1.4 g/cm³
- Skin formation time: 10–20 mins *)
- Tack free time: 20–30 mins *)
- Layer thickness: 0.2 mm
- Cure rate: approx. 3.5 mm/24 h *)
- Shore-A-hardness (DIN 53505): 55–60 *)
- Application temperature: 15°C to 35°C
- In service temperature range: -40°C to 100°C

CONTACT