

Montageanleitung Carbon Schwingenschutz BMW S1000 RR Fitting Instruction Carbon swing arm cover BMW S1000 RR

Stand 01/10

Anbau:

1. Die Schwinge muss trocken und fettfrei sein.
2. Den Kleber (Terostat 9220) möglichst dünn an vielen Stellen an der Schwinge auftragen
3. Die Schoner anschließend möglichst fest an der Schwinge andrücken und mit Kabelbindern fixieren um eine spaltfreie, feste Passung zu gewährleisten.
4. Den Kleber über Nacht antrocknen lassen.

Mounting:

1. The swing arm should be dry and greaseless.
2. Put the glue fine on the swing arm to many positions
3. Push the covers hard on the swing arm and fix it with cable clips to receive a gap free, exact fitting.
4. Let the glue dry over night.



Technical Data Terostat 9220:

- Colour: black
- Density: approx. 1.4 g/cm³
- Skin formation time: 10–20 mins *)
- Tack free time: 20–30 mins *)
- Layer thickness: 0.2 m
- Cure rate: approx. 3.5 mm/24 h *)
- Shore-A-hardness (DIN 53505): 55–60 *)
- Application temperature: 15°C to 35°C
- In service temperature range: -40°C to 100°C