

Montageanleitung EWS Antenne / Zünd-Kippschalter Mountingsheet immobilizer antenna / ignition switch

Zünd-Kippschalter:

Zum Anbringen des Zünd-Kippschalters muss ein Loch mit 12 mm Durchmesser an geeigneter Stelle gebohrt werden. Die Position ist frei wählbar beziehungsweise nur durch die Länge des Anschlusskabels begrenzt. Empfohlen wird die Position wie im Bild dargestellt, seitlich unter dem Drehzahlmesser. (auf ausreichend Abstand zur Verkleidung achten!)

EWS Antenne:

Die EWS Antenne kann hinter dem Armaturenbrett befestigt werden.

ACHTUNG: bitte den Werkstatsschlüssel (wird mit dem Motorrad ausgeliefert) wie auf der EWS Antenne abgebildet auflegen und mittels der im Lieferumfang enthaltenen Kunststoffbox zusammen verschrauben.

Ignition switch:

For mounting the ignition switch, drill a hole with 12 mm diameter on a free position. The position of the switch is user defined, but it is bounded by the length of the wire. It is advisable to install the switch like the picture shows, sideways under the rev. counter. (Please note: check enough desistance to the fairing!)

Immobilizer antenna:

It is possible to mount the antenna behind the dashboard. Please note: Please attach the master key (you got it with your bike) like the photo shows, on the antenna and fix it with the plastic cover.

