

## Montageanleitung Sturzpads BMW S1000 RR Mounting instructions frame crash pads BMW S1000 RR

### Anbauhinweise:

#### 1. Sturzpads für Original Verkleidung (rechtes Foto)

Sturzpads werden mit den mitgelieferten Alubuchsen in Richtung Rahmen angebracht. Der längere Pad für die linke Motorradseite mit der beiliegenden Inbusschraube M10x 70mm (10.9) anbringen. Den kürzeren Pad mit der Inbusschraube M10x75 (10.9) an der rechten Seite am Rahmen verschrauben (Drehmoment beider Schrauben 56 Nm).

#### 2. Sturzpads für Racing Verkleidung

Sturzpads werden mit den mitgelieferten Alubuchsen in Richtung Rahmen angebracht. Der längere Pad für die linke Motorradseite mit der beiliegenden Inbusschraube M10x 70mm (10.9) anbringen. Den kürzeren Pad mit der Inbusschraube M10x75 (10.9) an der rechten Seite am Rahmen verschrauben (Drehmoment beider Schrauben 56 Nm).

### Mounting Instruction:

#### 1. Crash Pads for Original Fairing

Mount the crash pads with alu bushing in frame direction. The longer pad fit with the M10x70mm (10.9) screw on the left side. The shorter pad with alu bushing and a M10x75mm screw on the right side. (56 Nm torque for both screws).

#### 2. Crash Pads for Racing Fairing

Mount the crash pads with alu bushing in frame direction. The longer pad fit with the M10x70mm (10.9) screw on the left side. The shorter pad with alu bushing and a M10x75mm screw on the right side. (56 Nm torque for both screws).

